



Item no. 301/404
Manufacturer's no. 23721

Slider Seal

THETFORD

Information

Pack size	17.4 x 13.6 x 2.6 cm
Net weight	49 g
Gross weight	49 g
Catalogue page	470

Slider seals of toilet cassettes become porous over time and should therefore be replaced regularly. To do this, simply remove the blade cover plate and pull the covers of the guide rails upwards. Then remove the screws and the cover plate to gain access to the slider seal. Remove the old slider seal, clean the area, insert the new blade seal with the thin flange side down and screw the cover plate back in place. Finally, spray the seal with a little Vaseline spray.

To slightly delay wear, simply clean the blade seal occasionally with a damp cloth.

For toilets from 15/06/2000*.

* only for C-2, 3, 4. All other models need this seal.

Specifications

Suitable for C2, C3, C4, C200, C250, C260, C400, C500