



Item no. 601/559
Manufacturer's no. 19847N4

Foot Pads for Camp Bed



Information

Dimensions	10x4x10 cm
Pack size	22x13x6 cm
Net weight	700 g
Gross weight	900 g

The Foot Pads can be easily attached to the round or straight frame of the Disc-O-Bed or Kid-O-Bunk. To do this, simply remove the rectangular rubber plugs from the straight frame and slide the foot pads onto it (pressing the foot pads slightly apart). The ribbed underside of the foot pads is designed to prevent slipping on smooth ground and to protect the groundsheet.

Specifications

Colour	black
Content	4 pieces
Material	plastic